
Electric height adjustable desk Assembly instructions


1-leg standing desk




PACKAGE CONTENTS





DESK COMPONENTS




HARDWARE














Assembly instructions - 1 leg desk

Step 1

1. Place the feets on a flat surface, and fix the plastic feet glides (G5).

Step 2

- 1. Place the shorter foot beam (C4) towards the back end, near the plastic feet glides. Secure it with four M6×14 screws (G2).
- 2. Place the longer foot beam (C5) on the remaining mounting holes. Secure it with four M6×14 screws (G2).

Step 3

1. Install the fixing plate by using six M6×14 screws (G2). For easier installation, attach all six screws loosely before tighten each one.

Step 4

1. Place the leg upside-down in a standing position. Attach the remaining four M6×14 screws (G2) to the leg.

Step 5

1. Attach the side frames to the leg by using four M6×12 screws (G1). Make sure that the rubber spacers are facing upwards towards the table top you will install in the next step.

Step 6

- 1. Place your table top on a flat surface. Place your frame assembly on top of it, adjust so the overhang is even on all sides.
- 2. Secure the tabletop to the frame, using the included tapping screws 5×20mm (G3).
- 3. Use two tapping screws 4×16mm (G4) to fix the handset (G6).

Step 7

- 1. Use the double sided velcro pad to fix the power adapter to desired position.
- 2. Connect the leg cable (yellow contact) to the backside of the handset.
- 3. Connect the power adapter (G7) to the port next to the leg cable on the handset.
- 4. Plug the power coord to the power adapter. Plug your desk into a electrical outlet.

Note! Before using your desk, a desk reset is required. See chapter 1 in your user manual for the handset.